

Installation Procedure

1. Wall mounted IP54

A. Mounting to wall

- Mark the mounting holes on the wall using the drawing provided
- Drill the hole for the wall plugs
- Hook the Digital Signage onto the wall
- Fasten all the 4 nos screws firmly



B. Accessing the Connection Panel, Power and Fan Filter

- Open the door of the digital signage
- The door will be supported by the gas springs
- On the right side of the chassis, there are 2 nos M6 screws
- Release the M6 screws using the extended box spanner (provided)
- Swing the LCD panel out of the chassis by 90 deg



C. Connecting the Digital Signage

- 4 types of inputs are available
- VGA, S-Video, Composite Video (AV) and TV
- VGA => D-Sub 15 way
- Composite Video => RCA, video, audio left & right
- S-video => mini 4-pin DIN
- TV => Antenna signal input



D. Control

- For LCD control, only the remote control is available
- The Infra red receiver is mounted at the top of the LCD swing frame
- To control the LCD, the door has to be opened
- This is to prevent un-authorized controlling of the LCD

